



## DETAIL

**NOTES:**

1. SILT FENCE SHALL BE INSTALLED BEFORE ANY EARTH REMOVAL OR EXCAVATION TAKES PLACE.
2. SET POSTS MAXIMUM 8 FEET ON CENTER AND EXCAVATE 6"x6" TRENCH UPSLOPE ALONG THE LINE OF POSTS.
3. ATTACH FILTER FABRIC TO POSTS AND EXTEND IT INTO TRENCH.
4. BACKFILL AND COMPACT EXCAVATED SOIL.

DRAWN BY: JSH  
 CHECKED BY: RJH

APPROVED BY:  
 DIRECTOR OF PUBLIC WORKS

# CITY OF BOULDER, COLORADO PREFABRICATED SILT FENCE INSTALLATION

ISSUED: JULY 2, 1998  
 REVISED: OCT. 17, 2000

DRAWING NO.  
 7.26